



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **2005-2010 Charger/Magnum/300 Polished Upper Hood Cap Part #303022**



**Your cover comes to you with a protective liner. Do not remove liner until final installation.**

- 1.** Remove the two bolts holding in place the hood catch cross bar. (NOTE: IF YOU WILL BE INSTALLING OUR HEADER PLATE BE SURE TO REPLACE THESE BOLTS WITH THE SPECIAL FLAT BOLTS THAT ARE PROVIDED WITH YOUR HEADER PLATE). Set bolts aside.
- 2. NOTE:** A friend would be very helpful for this next step. Placing the cross bar back in position as you place your new insert over it and arrange its position onto the hood so that you can achieve thru access at both hole locations. Replace the cross bar bolts that you just removed.

#### **CARE AND MAINTENANCE:**

**Note:** Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

**If any questions occur during installation please call American Car Craft at 727-861-1500.**

**Thank you and enjoy your purchase!**

**American Car Craft  
18924 Sakera Rd. Hudson, FL. 34667  
727.861.1500  
[www.AmericanCarCraft.com](http://www.AmericanCarCraft.com)**