



Water Tank Cover w/cap Polished

2011-2015



AMERICAN CAR CRAFT INSTRUCTIONS

Charger Water Tank Cover

Part# 333002



PARTS INCLUDED:

- 1- Stainless Cover
- 1- Adhesive Promoter Pack
- 1- Yellow 1/4" Spacer
- 1- 3/4" Chrome Decorative Cap Covers w/Velcro
- 1- 3/4" #12 Pan Head screw
- 1- Set of white socket cap cover with chrome top
- 4- 2 inch Velcro Cookies

Do not remove this liner until prompted by instructions.

- 1.** Remove the water tank pressure cap. Remove the factory bolt just above and to the right side of the tank. Then turn the water tank clip on the top of the water tank down wards, so that the clip does not dig the metal when fastening the water tank down. NOTE: This factory bolt will not be reused.
- 2.** You have been provided with a couple sets of 2" Velcro cookies. These are used for the front right of the water tank to help support the uneven shape of the factory water tank. Place a couple on the front part of the water tank closet to the driver fender to contact the factory water tank and the new stainless cover.
- 3.** Now place the new cover over the water tank and align the bolt hole with the one on the cover. Make sure to place the yellow spacer between the metal and the plastic on the water tank, where the bolt will be fastened using the pan head screw provided. Make sure to put the white socket clip on before you tighten the bolt down this will be used to snap the chrome cap cover onto the bolt head. Be carefully not to OVER tighten the screw as this will distort the new cover. Just snug will be sufficient.

4. You have been provided with a chrome decorative cap cover, simply clean the factory cap with household alcohol and then swipe once with the adhesive promoter provided then install the chrome cap by using the Velcro attachment cookies that are attached.

NOTE: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean California Duster first to prevent any particles from scratching them. Then wipe (using a new clean soft cloth or better yet Bounty paper towels) with a good quality streak free glass cleaner. **PLEASE SEE ENCLOSED CARE SHEET.**

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com