



AMERICAN CAR CRAFT INSTRUCTIONS

881008-Carbonfiber Replacement Illuminated Corvette Font Doorsills w/ Brushed Trim

PARTS INCLUDED:

- 2- Doorsills with wire attached
- 4-Red T-Taps
- 4- Red Spade Connectors
- 1-Pack of Adhesive Promoter
- 1-20inch 16ga wire.

**These instructions are in a video form on our YouTube channel. Under
playlist 2020 C8.**

<https://www.youtube.com/c/Americancarcraft/playlists>

**If any questions or problems occur during installation, please contact American Car Craft at
727-861-1500.**

Thank You and Enjoy Your Purchase!

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**