



AMERICAN CAR CRAFT INSTRUCTIONS

883011-Fender Covers Brushed Polished Perforated Inserts

- 2- Packets of Promotor**
- 2- Fender Covers Brushed Polished Perforated Inserts.**
- 1-Small Center Top plate with tape**
- 2- End Caps with tape.**
- 2- $\frac{3}{4}$ Polished caps**

**These instructions are in a video form on our YouTube channel.
Under playlist 2020 C8.**

<https://www.youtube.com/c/Americancarcraft/playlists>

Thank you and enjoy your purchase!

If any questions occur during installation, Please Contact.

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500

www.americancarcraft.com