



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **883030-Perforated Shock Tower Cover Inserts**

**PARTS INCLUDED:**

2-Perf Shock towers

1-Pack of Adhesive Promoter

2-Chrome caps with notch

4- Decorative Chrome Cap

1-Small tube of silicone

2-Chrome ½ Molding Strips at 19”

**These instructions are in a video form on our YouTube channel. Under  
playlist 2020 C8.**

**<https://www.youtube.com/c/Americancarcraft/playlists>**

**If any questions or problems occur during installation, please contact American Car Craft at  
727-861-1500.**

**Thank You and Enjoy Your Purchase!**

**AMERICAN CAR CRAFT  
18924 SAKERA RD HUDSON FL 34667  
Phone: 727 861-1500      Fax: 727 861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**